

## Guide to Sending Tone in Studio E

1. Press the Setup/Osc button twice. This should bring you to the “Osc Gen” page on the screen.



2. Make sure that the Source, Send To and Level settings match those seen in the picture at the right. Source should be “1Khz”, Send To should be “All” and Level should be “-20.”



3. Press the right-most knob below the screen. You should see the screen toggle from “Out” to “In” and you should now be hearing tone. If not, check that your speaker volume is set properly.



4. Press the right-most knob again to turn tone off.