

Guide to hooking up Studio B DVD Player

1. Make sure the Color Corrector is turned on. It is the small box on top of the DVD player. Also make sure it is set to either input 1 or input 3.



2. Connect RCA cables to the “DVD Output” panel on the back of the rolling cart. If you’re using the DVD Player outside of the control room, you may wish to connect RCA cables from the audio output to the speaker input panel. This will allow you to use the speakers that are included on the rolling cart.



3. Connect the other end of the RCA cables to the RCA inputs on the video rack.



4. Select “RCA In” on the routing switcher. This will make the DVD image show up on the frame sync input on the switcher. The image should also appear on the frame sync monitor.



5. Move to the audio patch bay. Connect patch cables from the “Patch RCA” outputs on the top row to a set of inputs on the second row. Then fade up the matching inputs on the audio console.

