

Guide to Monitoring VTR 2 channels 3 and 4

1. When playing back a DV or DVCAM tape recorded with four channels of audio, you need to use VTR2. On the mixing console, press the “Flip” button to switch to the second set of faders.



2. Fade up channels 11 and 12. Channel 11 corresponds to VTR2 Channel 3 and 12 corresponds to VTR2 Channel 4. These can be treated just like any other source.



3. To return to the main set of faders, press the flip button again.
4. As an alternative method for accessing channels 3 and 4 without using the flip button, you may use the pots above faders 11 and 12.