

Guide to Selecting a Source for the Waveform/Vectorscope

1. Select either “WFM A” or “WFM B” on the Auxiliary routing panel below the Waveform/Vectorscope. These correspond to the A and B inputs on the scope.



2. Select a source using any of the highlighted buttons below. These are the same sources that are available on the MLE busses of the switcher.



3. Use the SDI button to select the appropriate input, A or B, corresponding to the input you chose in step 1.



4. The “NEXT” button in the upper left can be used to cycle through the various displays. For more in-depth information about using the Waveform/Vectorscope, ask a Studio staff person.